

INSTRUCCIONES PAR LINEA DE RELOJES 3 ATM

IMPORTANTE


1. Puede usarlo mientras nada o lavando el auto, pero no presione ningún botón dentro del agua.
2. No usarlo en un ambiente extremadamente frío o caliente
3. No lo deje caer en un piso duro. El reloj puede aguantar una sacudida normal, pero no un golpe duro. Cualquier golpe duro pueden causarle daño.
4. No lo use en lugares llenos de gasolina, detergente, aceite, etc, sus acciones químicas dañarían el oro, la caja y la superficie del reloj.
5. Limpie la superficie de reloj con un paño suave y agua, no use sustancias químicas.
6. Algunos relojes tienen modelos impresos sobre la malla del reloj, no los limpie enérgicamente
7. No ajuste la malla demasiado apretada alrededor de su muñeca. El ajuste razonable es cuando puede introducir un dedo entre la malla y su muñeca.
8. Ponga el reloj en un ambiente seco cuando no lo use.
9. La superficie del reloj se puede decolorar y desgastar bajo presión pesada, mucho tiempo de toqueteo, abrasión o fricción.
10. La malla del reloj está hecha de resina, por lo tanto si encuentra cualquier polvo blanco en la malla, sáquelo con un paño, el polvo no causaría ningún daño a su piel ni prendas. La resina con que fue hecha la malla puede ir envejeciendo, agrietarse o romperse cuando soporta mucho sudor o humedad. Por lo tanto saque la suciedad o el goteo con un paño suave cuanto antes.
11. El reloj está hecho de partes electrónicas de precisión, no abra la tapa por su cuenta. Si hay agua o gotas dentro de la caja del reloj, pídale a un especialista desarmar y reparar inmediatamente, o las partes interiores pueden dañarse por causa de la corrosión.
12. Guarde bien las instrucciones de operación por uso necesario en el futuro.

VISOR ESTÁNDAR Y FUNCIONES DE BOTONES

Opere y ajuste el reloj de acuerdo a las siguientes indicaciones en la pantalla.

SEÑALES DE INDICACION/POSICIÓN DE BOTONES/FUNCIONES

☞ Alarma encendida
 A- AM AM
 P- PM PM
 L-LIGHT Botón de luz
 (c/ 3 segundos de duración)



M - MODE Botón p/ selección funciones
 S-START Botón p/avance-p/ver fecha-p/encendido y apagado de conteo de cronómetro
 R-RESET Botón p/ajuste de hora-p/ajuste de hora alarma-p/volver a cero en función cronómetro


NOTA: diferentes clases de relojes tienen diseños diferentes, pero tienen las mismas funciones y maneras de uso

FUNCION Y ESPECIFICACION

1. Visor estándar: hora, minuto, segundos, mes, fecha, semana
2. Función de luz
3. Función de cronómetro
4. Función alarma
5. Función para dormir/repeticón de alarma
6. Función señal horaria
7. Pilas: 1.5V alta capacidad, alcalina Zn-Mn botón de pila

OPERACIÓN

Presione "M", el modo cambiaría como sigue:



M: cuando está operando en la función cronómetro o ajuste de la hora de la alarma, si "S" o "R" son presionadas anteriormente, presionando el botón "M" puede volver al visor normal con la hora directamente.

- * Estando en el "Visor normal con la hora" presione "S" y verá la fecha; presione "R" y verá la hora de la alarma
- * **12/24 Visor de hora y fecha:** estando en el "Visor normal con la hora", presione "M" tres veces para entrar al modo de "Ajuste de horario y de fecha", comience a presionar "R" para posicionarse donde desea (hora, minutos, segundos, día, mes) y cuando esté en la posición deseada la misma comenzará a titilar y luego deberá presionar "S" para colocar el número deseado, luego de realizar los ajustes deseados debe presionar "M" para regresar al visor normal con la hora.
- * **Fijar hora de la Alarma:** estando en el "Visor normal con la hora", presione "M" dos veces para entrar al modo ajustado alarma, luego presione "S" para ajustar la hora, luego presione "R" una vez para pasar a los minutos y presione "S" para ajustar los minutos, finalmente presione "M" para regresar al visor normal con la hora.
- * **Función Cronómetro:** estando en el "Visor normal con la hora", presione "M" una vez para entrar al modo cronómetro, presione "S" para comenzar el conteo, y luego "S" para pararlo; presione "R" si desea volver el cronómetro a 0:00, finalmente presione "M" para regresar al visor normal con la hora.
- * **Encendido/apagado de alarma y señal horaria:** mantenga presionado "R" y a la vez presione "S" para encender o apagar la función alarma, cuando la alarma está encendida, el símbolo de la misma aparecerá en el visor. Cuando la alarma suene presiones "S" para pararla. Sonará nuevamente luego de 4-5 minutos, presione "R" para que no suene nuevamente. Mantenga presionado "R", y luego presione "M" para encender o apagar la función de señal horaria, cuando la señal horaria esté encendida, la semana completa se mostrará en el visor.
- * Luz: presione "L" para encender la luz, durará 3 segundos encendida. **Nota:** el uso prolongado de esta función tiene consumo de energía.

The enterprise has past the ISO9001:2000 Quality Control System Verification

INSTRUCTION FOR 3-BAR WATER RESISTENT SPORTS WATCH

NOTICE


1. You can wear it while swimming or washing car, but don't press any buttons in water.
2. Do not wear it in broiling or freezing environment.
3. Do not wear it in puissant electric field, static or high cycle environment.
4. Do not drop it onto hard ground. The watch can bear normal shake but not hard shock. Any rough use or hard shock may cause damage.
5. Do not wear it in the places having gasoline, detergent, spraying agent, adhesion agent, oil paint, etc., their chemical action would damage sealing ring, watchcase and watch surface.
6. Rinse watch surface with soft cloth and clear water, don't use chemicals.
7. Some watches have silk-screen-printing patterns on the watchband, don't rinse them forcibly.
8. Do not stretch the watchband too tightly around your wrist. The tightness is reasonable when your finger can insert in.
9. Place the watch in dry environment when unused.
10. The coating of watch may fade and scuff under heavy pressure, long-term touch, abrasion or friction.
11. The watchband is made from resin, so
If you find any white powder on the watchband, wipe them off with cloth, the powder would not cause any hurt to your skin and clothes.
The resin-made watchband may aging, crack or break when bear sweat or damp. Wipe off the dirt or drip with soft cloth as soon as possible.
12. The watch is made of precision electronic parts, don't open the cover by your self. If there is water smoke or drips inside the watchcase, ask approved specialist to disassembly and repair at once, or the inner parts may damage caused by corrosion.
13. Keep well the operation instruction and other attached files for necessary use in the future.

STANDARD DISPLAY AND BUTTON FUNCTION

Operate and adjust the watch according to the following indications on the screen.

SIGN INDICATION/BUTTON POSITION/FUNCTION

	ALARM ON
A AM	MORNING TIME
P PM	AFTERNOON TIME
L - LIGHT	COLD LIGHT BUTTON (with 3-second delay function)
M - MODE	FUNCTION SELECT BUTTON
S - START	DIGIT CARRY BUTTON DATE DISPLAY BUTTON STOPWATCH TIMEKEEPING ON/OFF BUTTON
R - RESET	TIME ADJUST BUTTON ALARM TIME DISPLAY STOPWATCH RESET BUTTON




NOTE: Different models have different designs, but have same functions and operation ways.

FUNCTION AND SPECIFICATION

1. Standard display: hour, minute, second, month, date, week
2. Cold light function
3. Stopwatch stage timekeeping function
4. Alarm function
5. Sleepy function
6. Hourly chime function
7. Service temperature: 5°C - 35°C
8. Degree of accuracy at normal temperature: ± 45 seconds every month
9. Battery: 1.5V high-capacity alkaline Zn-Mn button battery
10. Life of battery: able to supply power for 18 months under the following situation
 - 3 seconds of illumination everyday (3 seconds per cold light)
 - 60 seconds of alarm everyday (60 seconds per alarm)

OPERATION

Press "M" button, the mode would change in turn as following:



M*: When operating in "Stopwatch Function Operation Mode" or "Alarm Time Adjust Mode", if "S" or "R" button was pressed before, by pressing "M" button can back to "Normal Time Display Mode" directly.

- In "Normal Time Display Mode": press "S" button to display date; press "R" button to display alarm time.
- 12/24 Time System Display: In "Normal Time Display Mode", press "M" thrice to enter into "Time Adjust State", press "R" button twice to enter into "Hour Adjust State", then press "S" button until 12/24 Time System display on screen, and then press "M" once to back to "Normal Time Display Mode".
- Time Adjusting: In "Normal Time Display Mode", press "M" thrice to enter into "Time Adjust State", the second value blinks, press "S" to adjust second value; press "R" button, the minute value would blink, press "S" to adjust minute value; then press "R" and "S" respectively to adjust hour value, date, month, week; and then press "M" to back to normal mode.
- Alarm Time Setting: In "Normal Time Display Mode", press "M" button twice, then press "S" to set the hour value; press "R" once, then press "S" again to set the minute value, press "M" to back to normal mode.
- How to use stopwatch: In "Normal Time Display Mode", press "M" button once to enter into "Stopwatch Function Operation Mode", press "S" button to start timekeeping, press "S" again to stop timekeeping, the count value would display on the screen; Press "R" button to reset, press "M" button to back to "Normal Time Display Mode".
- How to on/off Alarm, Hourly Chime function: hold the "R" button, then press "S" to on/off Alarm Function; when "Alarm On", the signal would display on the screen, when the alarm ringing, press "S" to stop ringing. It would ring again after 4-5 minutes, press "R" to stop again-ringing. Hold the "R" button, then press "M" to on/off Hourly Chime Function, when Hourly Chime On, the week would display on screen.
- Cold Light Lamp: press "L" button to turn on the cold light with 3-second time delay. Note: long-term use of cold light would be power-consuming.



MADE IN CHINA